

# Maintenance Schedules

2017 Ford Transit	
Driving Condition:	Normal Condition
Cylinders:	6
Fuel:	Gasoline
Transmission:	Automatic
Engine Displacement:	3.5 L

## Recommended maintenance for your vehicle

This vehicle is equipped with Intelligent Oil Life Monitor (IOLM). Based on driving condition, the IOLM will display a message when your vehicle needs an oil change. Every time the display reads 'Oil Change Required', the following maintenance is recommended.



Change engine oil and replace oil filter when indicated on vehicle message center or every 12 months, whichever occurs first

MEMO: Gas engine; Up to 6.0 quarts of oil (IOLM)

Rotate and inspect tires; check wheel end play and turning noise

Inspect complete exhaust system and heat shields

Inspect and lubricate all non-sealed steering linkage, ball joints, suspension joints, half and drive-shafts and u-joints

Inspect automatic transmission fluid level (if equipped with underhood dipstick)

Inspect brake pads/shoes/rotors/drums, brake lines and hoses, and parking brake system

Inspect cooling system and hoses

Perform multi-point inspection

Mileage	30K	60K	90K	100K	120K	140K	150K
Check spring U-bolt torque	X	X	X		X		X
Change orange coolant				X			X
Replace accessory drive belts (if not replaced within last 100,000 miles)							X

Mileage	30K	60K	90K	100K	120K	140K	150K
Replace engine air filter	X	X	X		X		X
Replace spark plugs				X			
Replace Platinum spark plugs (6 cyl. Platinum)				X			
Change rear axle lubricant - synthetic only							X
Change automatic transmission/transaxle fluid and filter							X
Inspect accessory drive belt(s)				X	X	X	

Following the recommended Maintenance Schedule is the best way to keep your vehicles running right - it provides exactly what your vehicle needs, when it needs it. Visit [Genuine Ford and Lincoln Mercury Parts & Service website](#) for additional vehicle maintenance information.

[New Search](#)

[Print](#)